



## TYPICAL RELAXATION CURVES AT HIGH TEMPERATURES



NOTE: Initial load is 70% of specified minimum breaking strength.

## One Example of Estimated Long-Term Relaxation By Larson-Miller Method



NOTE: Initial load is 70% of specified minimum breaking strength.